

PROJECTION

These commands are usually used for projection of required plan (view)

- **Turn the plan** – push the mouse roller
- **Move the plan** - Ctrl + push the mouse roller
- **Zoom for/z** - Shift + push the mouse roller – roll the mouse roller
- **Zoom for everything**
- **Zoom window**
- **Zoom for chosen**
- **Perpendicularity**



Your work can be accelerated using toolbars **Standard plans** (view), which you can find in menu under the right mouse button, if you set the cursor to upper bar.

There are the tools for projection and orientation the model in the upper part of graphical area.



There are of the same name commands in the main menu.

